

# Nokia NetMonitor Manual

# **Nokia NetMonitor Manual**

by el.gambo

This is my new release (ver. 2.1a) of a NetMonitor manual for Nokia phones. It only contains the simple specifications for the great majority of screens. You can give suggestions and make corrections if necessary.

You can download this document (or new and improved version) from <http://www.mob385.com>  
Also, there you can find descriptions of most interesting displays with some more details (in Croatian only).

## **Information Sources**

Most of the info available at the moment comes from an official document from Nokia (rd843.txt).  
Some things were added, based on personal experiences and friends contributions.

## **Phone Models/Software versions**

### **31xx/81xx**

Old phones NetMonitor has some differences when compared with the new models, but this manual can be used as a guide, because the overall working method and the info given by the phone is very similar. However, I won't get into more details about old/new phones NetMonitor differences.

### **51xx/6xxx/71xx/8xxx/9xxx/3xxx**

This document covers the majority of menus from these phones NetMonitor. Some of them may have little differences, like missing/additional menus, different info, etc.

## **Activating the Field Test Display**

The Field Test Display is located at the end of the main menu loop.  
It is activated as follows:

- press the Menu button
- scroll in the main menu loop to field test display item (NETWORK MONITOR)
- press the Select button
- enter the index number of the test to be activated at the TEST NUMBER prompt
- confirm with the OK button

The field test data will then appear in a moment. The index number of the test will appear in the top right corner of the display. If given test number is not valid "No Test" -text will appear to the display.

A quicker way to activate the Field Test Display is to use the menu shortcut. The field test display is the last item in the main menu loop. The shortcut activation of the field test display is done in the following way:

MENU <number of the last item> <number of the desired field test display>

If the last number of the main menu loop is e.g. 8, in order to activate test display number 20, just press Menu, 8, 20 and OK in a sequence.

## **Deactivating the Field Test Display**

The Field Test Display is deactivated as follows:

- press the Menu button
- scroll in the main menu loop to field test display item
- press the Select button
- enter 0 at the TEST NUMBER prompt
- confirm with the OK button

## **Signal and battery levels**

When Field Test Display is active, normal signal and battery level bars are visible.

## **Reserving SIM SCM locations (recommendations)**

When starting to use a SIM-card in a phone with field test displays, it is recommended to put some default data into SIM SCM locations that are used by field test displays. This prevents accidental storing of phone numbers and names into such locations. Displays 52 and 53 also write some data to SIM SCM locations 35 and 36 overwriting any previous data.

| <b>SIM SCM location</b> | <b>Recommended number</b> | <b>Recommended text (name)</b> | <b>Location used by display</b> |
|-------------------------|---------------------------|--------------------------------|---------------------------------|
| 31                      | 65535                     | AUD DSP 1                      | 71                              |
| 32                      | 65535                     | AUD DSP 2                      | 72                              |
| 33                      | 0                         | BTS TEST                       | 17                              |
| 34                      | 34                        |                                | 52, 53                          |
| 35                      | 35                        |                                | 52, 53                          |
| 36                      | 36                        |                                | 52, 53                          |

Reserving SIM SCM locations is not necessary if the user is sure that he/she will never select these displays using menu shortcut (which executes the display).

In DCT3 phones it is not possible to select the SIM location number where the number and the name will be stored. So, reserving a SIM location must be done by some PC software or, for example, by DCT2 phone.

## Menu Modes

There are three Menu Display modes:

- execute mode
- data display mode
- help mode

Different modes are marked in this manual as follows:

```
*****          ++++++          #####
*                +                #      #
*  Execute      +Data display+    #  Help  #
*   Mode        +   Mode   +      #  Mode  #
*                +                #      #
*****          ++++++          #####
```

The execute mode is entered from the menu by scrolling and selecting or shortcut. If the test index entered pertains to a test that resets a timer (test 80) for example, then the timer is reset as soon as the OK button has been pressed in the menu, and the data display mode takes over. In other words, the execute mode is of the one-shot type. To run another test in the execute mode, the Field Test Display menu must be re-activated.

During the data display mode, the field test data (e.g. carrier, power level, cell) is visible on the main display. During the help mode, one screen of instructions is shown for each test to make it easier to identify the test in question. A long press of asterisk (\*) is used to toggle between these two modes.  
(on some 3110 versions, the help screens follow the data display modes on the list)

The arrow keys (^,v) offer an easy way to switch to another test without using the menu. However, the data display mode remains, i.e. nothing will be executed or set on although such tests would be passed. This is to prevent the user from accidentally clearing any valuable data. (see 3.7.2 for details and 2.5 for recommendations).  
The help mode is also a non-execute mode. Display numbers have been selected in such way that no 5-terminated test number is an execute display.

## Display 1 – Serving cell info



```

+++++#####
+abbb ccc ddd+  #CH RxL TxPwr#
+ e ff g mmmm+  #TS TA RQ RLt#
+ nnn   ppp+    # C1      C2 #
+   oooo  +     #   CHT   #
+++++#####
  
```

- a H, if carrier numbers are scrolled when hopping is on. Otherwise ' '.
- bbb When mobile is on TCH: DCH carrier number in decimal.  
When mobile is NOT on TCH: CH means carrier number in decimal.  
If hopping is on, used channels are scrolled when display is updated.
- ccc RX level in dBm, minus sign not shown if <=-100
- ddd TX power level. If transmitter is on, symbol \* is shown in front of the power level value (PL).

| PL:    | 5   | 6   | 7   | 8   | 9   | 10  | 11   | 12   | 13   | 14   | 15   |
|--------|-----|-----|-----|-----|-----|-----|------|------|------|------|------|
| dB:    | 33  | 31  | 29  | 27  | 25  | 23  | 21   | 19   | 17   | 15   | 13   |
| Watts: | 2.0 | 1.3 | 0.8 | 0.5 | 0.3 | 0.2 | 0.13 | 0.08 | 0.05 | 0.03 | 0.02 |

These values can easily be calculated using the following formulas:  
 $dB = 33 + (PL-5)*2$                        $Watts = (2/1995) * (10^{(dB/10)})$

- e Time Slot, range is 0 - 7
- ff Timing advance, range is 0 – 63
- g RX quality (sub), range is 0 - 7
- mmmm Radio Link Timeout value. If value is negative, 0 is shown.  
Maximum value is 64. When mobile is NOT on TCH then xx is shown.
- nnn value of the path loss criteria (C1). Range is -99 - 999.
- oooo type of current channel:
  - THR0 : TCH HR subchannel 0
  - THR1 : TCH HR subchannel 1
  - TFR : TCH FR
  - TEFR : TCH EFR
  - F144 : TCH FR data channel, speed 14.4 kbps
  - F96 : TCH FR data channel, speed 9.6 kbps
  - F72 : TCH FR data channel, speed 7.2 kbps
  - F48 : TCH FR data channel, speed 4.8 kbps
  - F24 : TCH FR data channel, speed 2.4 kbps
  - H480 : TCH HR data channel, speed 4.8 kbps, subch 0
  - H481 : TCH HR data channel, speed 4.8 kbps, subch 1
  - H240 : TCH HR data channel, speed 2.4 kbps, subch 0
  - H241 : TCH HR data channel, speed 2.4 kbps, subch 1
  - FA : TCH FR signalling only (FACCH) channel
  - FAH0 : TCH HR signalling only (FACCH) channel, subch 0
  - FAH1 : TCH HR signalling only (FACCH) channel, subch 1
  - SDCC : SDCC
  - AGCH : AGCH
  - CCCH : CCCH
  - CBCH : CCCH and cell broadcast receiving on
  - BCCH : BCCH
  - SEAR : SEARCH
  - NSPS : MS is in No Serv Power Save state
- ppp Value of the cell reselection criteria (C2).  
Range is -99 - 999. If phone is phase 1 then C1 value is shown.

## Display 2 – More info about serving cell




```

+++++++
+ aa b c Bdd +
+ ee f      +
+ ggg hh iii +
+ H=j mm nn +
+++++++
#####
#PM RAR Ro BC#
#RelR QLF  #
#CRO TO Pent #
#H MAIO HSN #
#####

```

- aa        Paging mode
  - NO : normal paging
  - EX : extended paging
  - RO : paging reorganisation
  - SB : same as before
- b        Maximum number of Random Access retransmission
- c        Roaming indicator, values are R or empty.
- Bdd     Letter B and BSIC value, range is 0 - 63.
- ee       Reason of last call release.
  - This parameter is also present in test 63, you will find explanation there.
- f        RX quality (full), range is 0 - 7
- ggg     Cell reselect offset, range 0 - 126 dB.
  - 0 - 63 \* 2 dB. 'xxx' in active mode.
- hh       Temporary offset, range 0 - 60 dB.
  - 0 - 7 \* 10 dB. 70 dB means infinite time.
  - 'xx' in active mode.
- iii     Penalty time, range 0 - 620 s.
  - 0 - 31 \* 20 s. 'xxx' in active mode.
- j        Hopping channel
  - 0    Single RF channel
  - 1    RF hopping channel
- mm     Mobile allocation index offset, MAIO
  - Range: 00 to 63 / xx when H=0
- nn     Hopping sequence number, HSN
  - Range: 00 to 63 / xx when H=0

## Display 3 – Serving cell, 1st and 2nd neighbour



```

+++++++
+aaabbbcccd+
+aaabbbcccd+
+aaabbbcccd+
+    ef gh  +
+++++++
#####
#SCH C1 rx C2#
#1CH C1 rx C2#
#2CH C1 rx C2#
#    1N 2N  #
#####

```

1. row: serving cell information
2. row: 1. neighbour information
3. row: 2. neighbour information
4. row, ef: 1. neighbour information
4. row, gh: 2. neighbour information

- aaa       Carrier number in decimal
- bbb     C1 value, range is -99 - 999, displayed only in idle mode.
  - Instead of C1 value, letter 'B' and BSIC value will be displayed in active mode.
- ccc     RX level in dBm, minus sign not shown if <=-100
- ddd     C2 value, range is -99 - 999
- e,g     F is shown if cell is in a forbidden location area otherwise location is empty.
- f,h     B is Barred, N is normal priority and L is low priority otherwise location is empty.

## Display 4 – 3rd, 4th and 5th neighbour cells

---



```

+++++++
+aaabbbcccddd+
+aaabbbcccddd+
+aaabbbcccddd+
+ ef gh ij +
+++++++
#####
#3CH C1 rx C2#
#4CH C1 rx C2#
#5CH C1 rx C2#
# 3N 4N 5N #
#####

```

1. row: 3. neighbour information
2. row: 4. neighbour information
3. row: 5. neighbour information
4. row, ef: 3. neighbour information
4. row, gh: 4. neighbour information
4. row, ij: 5. neighbour information

aaa Carrier number in decimal  
bbb C1 value, range is -99 - 999, displayed only in idle mode.  
Instead of C1 value, letter 'B' and BSIC value will be displayed in active mode.  
ccc RX level in dBm, minus sign not shown if <=-100  
ddd C2 value, range is -99 - 999  
e,g,l F is shown if cell is in a forbidden location area otherwise location is empty.  
f,h,j B is Barred, N is normal priority and L is low priority otherwise location is empty.

## Display 5 – 6th, 7th and 8th neighbour cells

---



```

+++++++
+aaabbbcccddd+
+aaabbbcccddd+
+aaabbbcccddd+
+ ef gh ij +
+++++++
#####
#6CH C1 rx C2#
#7CH C1 rx C2#
#8CH C1 rx C2#
# 6N 7N 8N #
#####

```

1. row: 6. neighbour information
2. row: 7. neighbour information
3. row: 8. neighbour information
4. row, ef: 6. neighbour information
4. row, gh: 7. neighbour information
4. row, ij: 8. neighbour information

aaa Carrier number in decimal  
bbb C1 value, range is -99 - 999, displayed only in idle mode.  
Instead of C1 value, letter 'B' and BSIC value will be displayed in active mode.  
ccc RX level in dBm, minus sign not shown if <=-100  
ddd C2 value, range is -99 - 999  
e,g,i F is shown if cell is in a forbidden location area otherwise location is empty.  
f,h,j B is Barred, N is normal priority and L is low priority otherwise location is empty.

## Display 6 – Network selection display

---



```
#####  
#LReg  1_For#  
#1_Pre 2_For#  
#2_Pre 3_For#  
#3_Pre 4_For#  
#####
```

This display shows the last registered network country code and network code as well as the codes for four forbidden networks and the first 3 preferred networks.

```
+++++  
+aaabb aaabb+  
+aaabb aaabb+  
+aaabb aaabb+  
+aaabb aaabb+  
+aaabb aaabb+  
+++++
```

If three digit MNC is used (DCS1900), display looks different:

```
+++++  
+aaabbbaaabbb+  
+aaabbbaaabbb+  
+aaabbbaaabbb+  
+aaabbbaaabbb+  
+aaabbbaaabbb+  
+++++
```

1. row: last registered network - 1st forbidden network
2. row: 1st preferred network - 2nd forbidden network
3. row: 2nd preferred network - 3rd forbidden network
4. row: 3rd preferred network - 4th forbidden network

aaa Country code coded in BCD

bbb Network code coded in BCD, third digit can be 'F'



## Display 7 – System information bits for serving cell



```

+++++++
+E A H C I BR+
+a b c d e fg+
+ECSC 2Ter MB+
+ h i j+
+++++++
#####
#Serving Cell#
#System Info #
#Bits #
# #
#####

```

- a 1 is shown if emergency calls are supported, else 0
- b 1 is shown if attach-detach-procedure is allowed, else 0
- c 1 is shown if half rate channels are supported, else 0
- d 1 is shown if C2 values are broadcasted, else 0
- e 1 is shown if system information 7 and 8 are broadcasted, else 0
- f 1 is shown if cell broadcast is supported, else 0
- g 1 is shown if re-establishment is supported, else 0

The following items are used only in dualband phones:

- h In idle mode 1 is shown if Early Classmark (ECSC) sending is supported, else 0.  
In dedicated mode (conversation) X is shown.
- i In idle mode 1 is shown if 2-Ter messages are supported, else 0.  
In dedicated mode (conversation) X is shown.
- j MultiBand reporting decimal value (0,1,2,3) is shown if supported.  
This is shown both in idle and dedicated mode.

The following is picked from Phase2+ ETSI GSM 05.08 version 5.4.0, Section 8.4.3 "Additional cell reporting requirements for multi band MS".

For a multi band MS the number of cells, for each frequency band supported, which shall be included in the measurement report is indicated by the parameter, MULTIBAND\_REPORTING. The meaning of different values of the parameter is specified as follows:

| Value  | Meaning  |
|--------|--|
| 0 (00) | Normal reporting of the six strongest cells, with known and allowed NCC part of BSIC, irrespective of the band used.   |
| 1 (01) | The MS shall report the strongest cell, with known and allowed NCC part of BSIC, in each of the frequency bands in the BA list, excluding the frequency band of the serving cell. The remaining positions in the measurement report shall be used for reporting of cells in the band of the serving cell. If there are still remaining positions, these shall be used to report the next strongest identified cells in the other bands irrespective of the band used.        |
| 2 (10) | The MS shall report the two strongest cells, with known and allowed NCC part of BSIC, in each of the frequency bands in the BA list, excluding the frequency band of the serving cell. The remaining positions in the measurement report shall be used for reporting of cells in the band of the serving cell. If there are still remaining positions, these shall be used to report the next strongest identified cells in the other bands irrespective of the band used.   |
| 3 (11) | The MS shall report the three strongest cells, with known and allowed NCC part of BSIC, in each of the frequency bands in the BA list, excluding the frequency band of the serving cell. The remaining positions in the measurement report shall be used for reporting of cells in the band of the serving cell. If there are still remaining positions, these shall be used to report the next strongest identified cells in the other bands irrespective of the band used. |

## ***Display 8 – Preferred network selection***

---

In Nokia 6185/6188 it looks like follows:

```
+++++
+TADD TDROP +
+TCOMP TTDROP+
+WW1 WW2 WW3 +
+           +
+++++
```

TADD - threshold to add a new active PN (raw value ex: 28 = Ec/Io at -14 dB), [TDROP] : threshold to drop an active PN (raw value ex: 32 = Ec/Io at -16 dB)  
TCOMP - other threshold to add an active PN when a candidate PN becomes stronger than an active PN  
TTROP - timer to drop a PN when power of this PN goes below TDROP  
WW1 - value of the search window for the active PN  
WW2 - value of the search window for the neighbour PN,[WW3]: value of the search window for the remaining PN.

In Nokia 6210 it looks like follows:

```
+++++
+TS for Rx +
+TS for Tx +
+MainCh/PwrLv+
+           +
+++++
```

and is probably connected with HSCDS...

## ***Display 9 – Preferred network selection***

---

In Nokia 6185/6188 it looks like follows:

```
+++++
+006 330 270 +
+047 062 062 +
+342 102 030 +
+062 062 062 +
+++++
```


Tracked PN Offsets (lines 1,3) and EC/SO (Energy per chip per noise). An EC/SO of 062 likely means not really usable? lower numbers are better strengths). See test 2 for PN offset information.

In Nokia 6210 it looks like follows:

```
+++++
+MainCh/PwrLv+
+PwrLv TS 0-3+
+PwrLv TS 4-7+
+           +
+++++
```

and is probably connected with HSCDS...

## Display 10 – Paging Repeat Period, TMSI, Location Update Timer, AFC and AGC



```

+++++++
+TMSIaaaaaaa+
+T321:bbb/ccc+
+PRP:d ee ff+
+ ggggg hhh +
+++++++
#####
#TMSI(hex) #
#T321ctr/tim#
#PaRP DSF AGC#
# AFC Ch #
#####

```

- aaaaaaa TMSI value in hex format
- bbb Current value of T3212 counter (range is 000 - 'ccc', where 1 means 6 min time. So, if this value is 2 less than 'ccc' then next periodic location updating will be made within 2 \* 6 min = 12 minutes.
- ccc Timeout value of T3212 counter (range is 000 - 240, where 1 means 6 min time between location updates and 240 means 240 \* 6 min = 24 h between location updates. 000 means that periodic location update is not in use.) This value is received from the network.
- d Value of paging repeat period (range is 2 - 9, when paging is in every second multiframe, mobile takes more current than if it were in every 9th multiframe)
- ee Downlink signalling failure value. If value is negative, 0 is shown. Maximum value is 45. When mobile is on TCH then xx is shown.
- ff Gain value on TCH/SDCCH, range is 0 - 93
- ggggg VCTCXO AFC DAC control, range is -1024 - 1023
- hhh Serving cell channel number

## Display 11 – Network parameters



```


+++++++
+CC:aaa NCbbb+
+ LAC:cccc +
+ CH : dddd +
+ CID:eeee +
+++++++
#####
# MCC MNC #
#LocAreaCode #
#ServChannel #
# CellId #
#####

```

- aaa MCC value in decimal (MCC = Mobile Country Code)
- bbb MNC value in decimal (MNC = Mobile Network Code)  
Three digits are shown only in DCS1900.  
In other systems only two digits are shown.
- cccc LAC value in decimal (LAC = Location Area Code)
- dddd Serving cell channel number
- eeee Cell Identifier in decimal format

Some software versions display LAC and CID differently. These can be shown in hex format or even both decimal and hexadecimal formats on the same line.

## Display 12 – Ciphering, hopping, DTX Status and IMSI



```

+++++++
+CIPHER :aaa +
+HOPPING:bbb +
+DTX :ccc +
+IMSI :ddd +
+++++++
#####
#CipherValue #
#HoppingValue#
#DTXValue #
#IMSIAttach #
#####

```

- aaa Ciphering value, OFF/A51/A52
- bbb Hopping value, ON/OFF
- ccc DTX value ON/OFF
- ddd IMSI attach  
ON : IMSI attach on  
OFF : IMSI attach off

These values are updated only on the TCH.

## Display 13 – Uplink DTX switching display

---



```

+++++++
+aaaaaaaa +
+DTX(DEF):bbb+
+DTX(BS):ccc+
+           +
+++++++
#####
#DTXMode   #
#DefaulDTXSta#
#DTXValFromBS#
#           #
#####

```

With this display it is possible to change MS to use DTX or not, if BS allows MS to decide it.

This display must be activated from MENU to change DTX state. When MENU is not active and the user is scrolling field test displays with NEXT and PREVIOUS, the DTX state will not change.

```

aaaaaaaa Status of switched mode.
          DTX:ON: MS uses DTX
          DTX:OFF: MS does not use DTX
          DTX:DEF: MS use default state of DTX.
                    Defined in MS_PAR.H
          NOTALLOWED: BS does not allow MS to decide if it uses DTX or not.
bbb      Default state of DTX. Defined in MS_PAR.H
          The value is either ON or OFF
ccc      DTX value from BS
          MAY : BS allows MS to decide if it uses DTX or not on uplink.
          USE : BS controls MS to use DTX (on uplink)
          NOT : BS controls MS not to use DTX (on uplink)

```

## Display 14 – Toggle Screening Indicator

---

When selected, changes the value of Screening Indicator from 0 to 1 and vice versa.

```

*****
*  SCREENING  *
*  INDICATOR  *
*    IS xx    *
*             *
*****
#####
#Use menu to #
#  change   #
# Screening  #
# indicator  #
#####

xx = 00 or 01

```

## Display 15 – AMPS display

---

In Nokia 5190/6190 it looks like follows:

```
+++++#####
+aaa bbb cccc+ #CH RxL TxPwr#
+ ddd eee f + #MdSt SAT DCC#
+ gg hh ii + #ST TxA RxA#
+ jjjjjjjjjj + # CS STATE #
+++++#####
```

When you don't have additional module (it's between "main" phone and battery), you will see "AMPS display not available" here. After connecting it you will see values connected AMPS:

aaa - channel used for communication with cell (0 during standby)  
bbb - level of received signal in dB  
ccc - level of the transmitted signal (0 during standby)  
eee - SAT, x during standby  
f - DCC (Digital Color Code) on the ACCH channel (0-3, - = not locked), x during standby  
jjjjjjjjjj - cellular state:  
IDLE - standby  
CALL GOING - exchange of data required to make call  
IN CALL - during call  
PCH INIT - scanning available paging channels ? (for example, after call)  
CCH INIT - scanning control channels ?  
ACCESS - accessing network ?

In Nokia 6210 it looks like follows:

```
+++++
+Sent frames +
+Re-transmis.+
+Rec. frames +
+Re-send reqs+
+++++
```

## Display 17 – Switch BTS\_Test Status

---



```
*****  
*           *  
*  BTS TEST  *  
*    xx     *  
*           *  
*****  
#####  
#Use menu to #  
#toggle BTS #  
#test ON/OFF #  
#           #  
#####
```

xx = ON or OFF

ON: Mobile is searching only one frequency. Neighbour measurements are not done.

OFF: Mobile is behaving normally. Neighbour measurements are done.

This display is used to toggle BTS\_TEST status on EEPROM. If BTS\_TEST status is set on EEPROM each time the mobile sends a search list it uses only the carrier number stored on SIM SCM-location 33. Also the neighbour information from system information messages is ignored. If the BTS\_TEST status is not set, then the value of SIM SCM-location 33 is ignored and the mobile behaves normally (i.e. does the neighbour measurements according the GSM specifications).

To activate BTS tests perform following steps:

- Save desired channel number in SIM SCM-location 33.
- Select display 17 in execute mode
- Switch power off and on

If activation succeeded, there is text "BTS TEST ON" in display 17.

To deactivate BTS tests either select display 17 in execute mode or save number 0 in SIM SCM-location 33 and switch power off and on.

NOTE! The display does not show the value of BTS\_TEST status in EEPROM. Although the value is set, BTS test can be off. If there is not legal carrier number in SIM location 33 (GSM: 1-124, DCS1800: 512-885) the display shows that BTS test is off. Also if the mobile was already registered to some carrier before switching BTS\_TEST status, the display can show different value from the one in EEPROM.

## Display 18 – Lights status control

---

Forces keyboard and display lights on/off while displaying any NetMonitor screen.

```

*****
*           *
*  LIGHTS  *
*   xx    *
*           *
*****
#Use menu to #
# toggle   #
# lights   #
# ON/OFF   #
#           #
#####

```

xx = ON or OFF

## Display 19 – Toggle Cell Barred Status

---



```

#####
#Use menu to #
#toggle cell #
#barr status #
#DIS/ACC/REV #
#####

```

```

*****
*           *
* CELL BARR *
* ACCEPTED  *
*           *
*****
or
*****
*           *
* CELL BARR *
* REVERSE   *
*           *
*****
or
*****
*           *
* CELL BARR *
* DISCARD   *
*           *
*****

```

This test is meant to be used when some cells are tested prior taking them into commercial use. By setting the barring on in the base station normal GSM phones will not try to register these barred cells. By selecting cell barring reversed, the MS will only use the cells to be tested. However, if at the same time it is wanted that MS will be capable to use normal network cell barring ignored can be set. Display 19 will show the cell barring mode.

NOTE! If a cell has been selected before barring state is changed the selected cell may have different barring state than what the display shows. After reselection the cell barring state is working for sure.

## Display 20 – Charging status



```

+++++++
+ aaa  bbbbb +      #####
+ Tccc dddd +      #BatVol ChMod#
+ Ceee  Wfff +      #Btemp ChTime#
+ gggg  hhhh +      #ChrgVol Pwm #
+      +      # Btyp  BFDC #
+++++++
  
```

aaa Battery voltage in decimal, range is 0.00 - 9.99 V, decimal point is not shown; e.g. 7.19V is shown as 719 on the display

bbbbb Charging mode 5 digit symbol:

- xxxxx : Charger not connected or charging disabled.
- Charg : Charging.
- Maint : Maintenance charging.
- Faile : Failure.
- DisCh : Battery discharging going.
- InitC : EM charging is being initialised.
- BatCk : Battery testing is going.
- ChaCk : EM is checking charger.
- CelBr : Charging off because one or more cells broken inside battery.
- BSIFa : Charging off because of battery BSI measurement failed.
- TmpFa : Charging off because of battery NTC measurement failed.
- VolFa : Charging off because charger voltage measurement failed.
- CurFa : Charging off because charger current measurement failed.
- FastC : Fast charging going.
- FullM : Battery full and maintenance going.
- HotM : Battery hot and maintenance going.
- ColdM : Battery cold and maintenance going.
- TxOnC : TX on and Ni charging going.
- TxNoF : TX on, Ni charging going and battery is not full anymore.
- LithC : Charging of Lithium-ion battery.
- LiAFu : PWM level is below the battery full limit.
- LiFul : PWM has been below the battery full limit for a certain time that is specified for full battery.
- LiTxO : TX on and Li charging going.
- LNFTx : TX on, Li charging going and battery is not full anymore.
- ColdC : Cold charging.
- I\_Che : Init checks.
- L\_Che : Li charging checks.
- F\_Che : Fast charging checks.
- M\_Che : Maintenance charging checks.
- MaBFD : Maintenance BFD charging.
- LiDCH : Li-ion DCH charging.
- LiHot : Li-ion hot charging.

ccc Battery temperature in centigrade, from -30 to +90.

ddd Charging time. Format is HMM. Timer is automatically reset and started when charger is connected and stopped when battery is full or charger is disconnected.

eee Charger voltage in decimal, range is 0.0 - 18.7 V, decimal point is not shown.

fff Charge control output, decimal, range is 000 - 255.

gggg Lithium battery type (BSI value multiplied by 4), or NiMH battery size.

hhhh Battery full delay counter. When battery is getting full and charging current is less than predefined limit, this timer will be started. If timer reaches 0, charging will be stopped.



## Display 21 – Constant voltage charging display

---

```
+++++
+ aaaa bbbb + #####
+ cccc dddd + #MTDif MPDif #
+ eeee ffff + #BupV BDownV#
+           + #AverV SumMF #
+           + #           #
+++++
```

aaaa Difference between measured voltage and goal voltage, decimal point is not shown.  
bbbb Difference between measured voltage and result of previous measurement (basically same as using change of error), decimal point is not shown.  
ccc Battery up voltage, maximum ripple voltage.  
ddd Battery down voltage, minimum ripple voltage.  
eee Average voltage.  
fff Sum of membership function sets beliefs, range 0.00-9.99, decimal point is not shown; e.g. 1.53 is shown as 153. If sum of 1.00 is reached then battery full indication is given.

## Display 22 – Battery full detection

---

```
+++++
+ Eaaa Cbbb + #####
+ Dccc Rddd + #DeriC ChAm #
+ Ieee Afff + # VDif VDrop #
+ Tggg hhhh + # VDTi AvDif #
+           + # Temp Volt #
+++++
```

Letters E, C, D, R, I, A, T and V are displayed constantly.

Eaaa DerivCount membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
Cbbb ChargeAmount membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
Dccc VolDiffToMax membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
Rddd VolDropCnt membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
leee VolDiffTime membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
Afff AverDiff membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
Tggg Temperature membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.  
Vhhh Voltage membership function set, range 0.00-1.00, decimal point is not shown; e.g. 0.23 is shown as 023.

## Display 23 – Battery and phone state monitor

---



```

+++++++
+ aaaa bbbb +
+ cccc dddd +
+eee fff gggg+
+hhh iiii+jjj+
+++++++
#####
#TxOn TxOff#
#ChCur Stdby#
#Age CAP Curr#
#Tmp CmAhTarg#
#####

```

- aaaa TXon voltage, decimal point not shown (a.aaa mV)
- bbbb TXoff voltage, decimal point not shown (b.bbb mV)
- cccc Charging current, decimal point not shown (c.ccc mA)
- dddd Predicted standby level, decimal point not shown (d.ddd mV)
- eee Estimated age for Li-ion battery (0..100, 0=new, 100=old)
- fff Battery's percentage level (0..100)
- gggg Current consumption indicated by PSM (deci-mA)
- hhh Battery's temperature (C) (Only for Li battery)
- iii Charged capacity (mAh) (into battery)
- jjj Tells what is the next capacity target to reach next battery bar level (mAh)

## Display 24 – Battery indicators

---

```

+++++++
+ aaaa bbbb +
+ BSI: cccc +
+ ET: dddd +
+ eeee ffff +
+++++++
#####
#V_inst V_avg#
# BSI value #
#Elapsed time#
#RST_m RST_h#
#####

```

- bbbb (Voltage average) average value of voltage from battery
- ccc (Battery Size Indicator) info connected with battery
- dddd how many minutes phone work from enabling (minutes)
- eeee (Rest Standby Time minutes) does phone estimate here, how long phone can be in standby up to next charging (minutes)
- fff (Rest Standby Time hours) does phone estimate here, how long phone can be in standby up to next charging (hours)

## Display 30 – Audio API register display

---

```

+++++++
+ aaaa bbbb +
+ cccc dddd +
+ eeee ffff +
+ gggg hhhh +
+++++++
#####
#A1Cnf A2Cnf#
# ST AU3 #
#1Tone 2Tone#
# Conf HFVol#
#####

```

- aaaa API\_AUD1\_CTRL
- bbbb API\_AUD2\_CTRL
- cccc API\_SIDETONE
- dddd API\_AU3
- eeee API\_1\_TONE
- fff API\_2\_TONE
- gggg API\_CONFIG
- hhhh API\_HF\_VOL

### Display 34 – FBUS display

---

```

+++++++
+aaaaa - + #CM LD LM NM #
+bbbbbb- a -+ #PEC FEC OEC #
+cc + #ACC RXS TXS #
+H-- + #Mod #
+++++++

```

- aa Current FBUS media in hex
- bb Last sender dev in hex
- cc Last sender media in hex
- dd Next media to be connected. Same as aa if the connection is not pending.
- eee FBUS parity error counter
- fff FBUS framing error counter
- ggg FBUS overrun error counter
- hhh FBUS alive check counter
- iii RX Sequence number
- jjj TX Sequence number
- k Phone mode: S = slave, H = host

### Display 35 – Reasons for SW resets

---



```


+++++++
+aaaaa + #Reset reason#
+bbbbbbb + #Task name #
+ + # #
+ + # #
+++++++

```

- aaaaa Last reset reason.
  - NORM : Probably normal power up.
  - UNKNO : Default value, reset reason is unknown.
  - HW WD : ASIC watchdog timeout.
  - SWDSP : DSP recovery reset
  - SWSIM : SIM contact failure reset
  - SWIDL : Idle task not running reset
  - STACK : Task stack overflow
- bbbbbbb Name of running task before reset.

### Display 36 – Counters for resets

---



```

+++++++
+ aa bb cc + # UN WD DSP #
+ dd ee ff + #SIM IDL STK #
+ + # Reset #
+ + # counters #
+++++++

```

- aa Unknown resets
- bb ASIC watchdog resets
- cc DSP recovery resets
- dd SIM contact failure resets
- ee Idle task not running resets
- ff Task stack overflow resets

## Display 38 – Memory dump

---

```

+++++
+aaaaaaaa+   #####
+aaaaaaaa+   #Memory dump #
+aaaaaaaa+   #           #
+aaaaaaaa+   #           #
+aaaaaaaa+   #           #
+++++

```

aaaa.... hex dump of 24 successive memory locations


The start address of the dump is entered as 6 digit address value into SIM alpha memory location #30.

An example: address 0x0C89AB -> enter 'name' 0C2089AB into SIM alpha memory location #30.

Dump address is changed only when field test display #38 is selected via menu, changing memory location #30 is not enough! This display will not be included in official software, but designers can use it for their own test purposes. Display can be switched on by defining flag DEV\_FT\_MEMORY\_DUMP\_IN\_USE in ftd\_conf.h.

## Display 39 – Information about reasons for call clearing

---



```

+++++
+ CC: aaaa +   #####
+ MM: bbbb +   #CC CauseValu#
+ RR: cccc +   #MM CauseValu#
+           +   #RR CauseValu#
+           +   #           #
+++++

```

- aaaa      CC cause value, see section 10.5.4.11/GSM 04.08  
 '\*' is shown in front of cause value if cause is made up by CC layer in MS  
 This parameter is also present in test 63, you will find explanation there.
- bbbb      MM cause value, see section 10.5.3.6/GSM 04.08  
 '\*' is shown in front of cause value if cause is made up by MM layer in MS
- 2: IMSI unknown in HLR (SIM card not active in network)
  - 3: illegal phone
  - 4: IMSI unknown in VLR
  - 5: phone's IMEI was not accepted
  - 6: illegal ME
  - 11: PLMN not allowed (you tried to log into network, which doesn't have roaming convention with your home network - your phone displays 'No access', when you try to select it manually)
  - 12: Location Area not allowed. You can check it in test 11
  - 13: roaming not allowed in this Location Area
  - 17: network failure
  - 22: network congestion
  - 32: service option not supported
  - 33: service option not subscribed
  - 34: service temporarily out of order
  - 38: call cannot be identified
- cccc      RR cause value, see section 10.5.2.31/GSM 04.08  
 '\*' is shown in front of cause value if cause is made up by RR layer in MS
- 0: normal release
  - 1: unspecified
  - 2: channel unacceptable
  - 3: timer expired
  - 4: no activity on the radio path
  - 5: Pre-emptive release
  - 8: handover impossible, TA out of range
  - 9: channel mode unacceptable
  - 10: frequency not implemented
  - 65: call already cleared
  - 97: message type not compatible with protocol state
  - 101: no cell allocation available
  - 111: protocol error unspecified

## Display 40 – Reset handover counters

---

```

*****          #####
*   RESET      *   # Use menu #
*  HANDOVER    *   # to reset #
*  COUNTERS    *   # handover #
*              *   # counters #
*****          #####

```

With this display all timers of the handover display can be reset.

## Display 41 (singleband) – Handover display

---

```

+++++++          #####
+HandOOK: aaa+  #HandOvOKCntr#
+PrevCh : bbb+  #PrevChanCntr#
+HONotOK: ccc+  #HandOvNOKCnt#
+HOIntra: ddd+  #HOIntraOKCnt#
+++++++          #####

```

aaa Counter for successful handovers (max. amount 999)  
 bbb Counter for successful back to previous channel attempts  
 ccc Counter for failed handovers  
 ddd Counter for successful intracell handovers or assignments (max. amount 999)

Counters will stop when they reach their maximum. To initialise the counters to zero, select display 40. Display 60 also initialises these counters.

## Display 41 (dualband) – Handover display, INTER CELL

---



```

+++++++          #####
+ aaaa bbbb +   #G>G InterD>D#
+ cccc dddd +   #G>D OK D>G#
+eeefffggghh+  #InterHoFail #
+iiiijjjkklll+ # BackToPrev #
+++++++          #####

```

aaaa Counter of successful handovers (max 9999) from GSM to GSM  
 bbbb Counter of successful handovers (max 9999) from DCS to DCS  
 cccc Counter of successful handovers (max 9999) from GSM to DCS  
 dddd Counter of successful handovers (max 9999) from DCS to GSM

eee Counter for failed handovers (max 999) from GSM to GSM  
 fff Counter for failed handovers (max 999) from DCS to DCS  
 ggg Counter for failed handovers (max 999) from GSM to DCS  
 hhh Counter for failed handovers (max 999) from DCS to GSM

iii Counter of successful back to previous channel attempts (max 999) from GSM to GSM  
 jjj Counter of successful back to previous channel attempts (max 999) from DCS to DCS  
 kkk Counter of successful back to previous channel attempts (max 999) from GSM to DCS  
 lll Counter of successful back to previous channel attempts (max 999) from DCS to GSM

Counters will stop when they reach their maximum. To initialise the counters to zero, select display 40. Display 60 also initialises these counters.

## Display 42 (dualband) – Handover display, INTRA CELL

---

```

+++++
+ aaaa bbbb +
+ cccc dddd +
+eeefffggghh+
+iiijjjkkkl+
+++++
#####
#G>G IntraD>D#
#G>D OK D>G#
#IntraHoFail #
# BackToPrev #
#####

```

aaa Counter of successful INTRA CELL handovers (max 9999) from GSM to GSM  
bbb Counter of successful INTRA CELL handovers (max 9999) from DCS to DCS  
ccc Counter of successful INTRA CELL handovers (max 9999) from GSM to DCS  
ddd Counter of successful INTRA CELL handovers (max 9999) from DCS to GSM


eee Counter of failed INTRA CELL handovers (max 999) from GSM to GSM  
fff Counter of failed INTRA CELL handovers (max 999) from DCS to DCS  
ggg Counter of failed INTRA CELL handovers (max 999) from GSM to DCS  
hhh Counter of failed INTRA CELL handovers (max 999) from DCS to GSM

iii Counter of successful back to previous normal INTRA CELL channel attempts (max 999) from GSM to GSM  
jjj Counter of successful back to previous normal INTRA CELL channel attempts (max 999) from DCS to DCS  
kkk Counter of successful back to previous normal INTRA CELL channel attempts (max 999) from GSM to DCS  
lll counter of successful back to previous normal INTRA CELL channel attempts (max 999) from DCS to GSM

Counters will stop when they reach their maximum. To initialise the counters to zero, select display 40. Also display 60 initialises these counters.

## Display 43 - L2 display

---



```

+++++
+T200MS :aaaa+
+T200BS :bbbb+
+T200MS :cccc+
+T200BS :dddd+
+++++
#####
#T200 MS GSM #
#T200 BS GSM #
#T200 MS DCS #
#T200 BS DCS #
#####

```

aaaa GSM: Counts how many times T200 in MS has expired and therefore L2 transmission has been repeated.  
bbbb GSM: Counts how many times T200 in BS (network) has expired and therefore L2 transmission has been repeated.  
cccc DCS: Counts how many times T200 in MS has expired and therefore L2 transmission has been repeated. (for dualband phones)  
dddd DCS: Counts how many times T200 in BS (network) has expired and therefore L2 transmission has been repeated. (for dualband phones)

Counters will stop when they reach their maximum. To initialise the counters to zero, select display 40. Display 60 also initialises these counters.

## Display 44 – Toggle revision level

---

When selected, changes the value of Revision Level from 0 to 1 and vice versa.

```

*****
*          *
* REVISION *
*LEVEL IS xx*
*          *
*****
#####
#Use menu to #
# change #
# Revision #
# Level #
#####

```

xx = 01 or 02

## Display 45 – Toggle transmitter functionality

---

When selected, disables transmitter functionality if enabled and vice versa. New setting is valid until next power off or until new execute of this display.

```
***** #####
*          * #Use menu to #
*TRANSMITTER * # enable or #
*  xxxxxxxx * # disable  #
*          * #transmitter #
***** #####
```

xxxxxxx = ENABLED or DISABLED

This FTD can be used to simulate easily situations when the MS can hear the network (i.e. receiving signal is good enough), but the network can not receive any messages from the MS.

Location updating attempts or MO call establishment attempts can be failed (random access failure) by this FTD and field testing of these failures is much easier now.

Next periodic location updating can be checked from the display 10 (chapter 3.1.10) by taking the difference of current T3212 counter value and T3212 timeout value.

## Display 51 – SIM information

---



```
+++++#####
+aaa bbb ccc + #Vsel Bau SA1#
+ dddddddd + #SCond CStop#
+ f g hh ii + #PIN12 PUK12#
+ j kkkk + # ATR FE/PE #
+++++#####
```

|      |   |
|------|---|
| aaa  | SIM voltage selection type (5, 3 or 3/5)                    |
| bbb  | SIM baudrate (372, 64, 32 or 0)                             |
| ccc  | Clock stop allowed, Yes or No                               |
| ddd  | Clock stop condition, Up or down (preferred)                |
| eee  | Clock stopped, Yes or No (NOT IMPLEMENTED)                  |
| f    | PIN1 attempts left (0,1,2,3)                                |
| g    | PIN2 attempts left (0,1,2,3)                                |
| hh   | PUK1 attempts left (0-10)                                   |
| ii   | PUK2 attempts left (0-10)                                   |
| j    | ATR retransmission counter (0-9)                            |
| kkkk | Transmission frame/parity errors, FE/PE + hexadecimal count |

## Display 52 – Reading datafield from SIM card

---

```
+++++          #####
+ Read SIM-  +  # Use menu to#
+ data field +  # read SIM-  #
+ to SIM-SCM + # data field #
+           +  # to SIM-SCM #
+++++          #####
```

This display reads a binary datafield from SIM card to SIM SCM memory (SCM = Short Code Memory and it means phonebook on SIM card).

Prior using this display the identifier of datafield has to be stored as an alpha-identifier of SCM location number 34 of SIM memory. The datafield must be written in hexadecimal notation. The identifiers can be found from the GSM 11.11.

The contents of datafield is stored as a data-identifier of SCM location number 35 of SIM memory. The contents are displayed in hexadecimal notation. The maximum length of the datafield is 10 bytes, but the length depends on the name length of the SIM memory. In case the datafield cannot be read the alpha-identifier of SCM location is NOT DONE.

The information of how the read succeeded can be read from the SCM location 36 of SIM memory and on the display for a short period.

The following results are possible:

- OK datafield was read correctly
- NOT BINARY datafield is either formatted or cyclic
- NOT FOUND datafield was not found from SIM card
- CARD ERROR something weird happened, card did not respond as expected
- NO RIGHTS not enough rights to read the datafield (PIN2,adm..)
- NOT STORED could not store into the result memory place
- NO ADDRESS could not read the address from the SCM-location
- UNKNOWN unidentified error

For the time being following binary datafields exist in SIM. In future there could be more. All of these are not necessarily on all SIM cards.

- 2FE2 ICC identification (10 bytes)
- 6F05 Language preference (variable length)
- 6F07 IMSI (9 bytes)
- 6F20 Ciphering key Kc (it's read from card after entering PIN) (9 bytes)
- 6F30 PLMN selector (variable length)
- 6F31 HPLMN (home network ?) search period (1 byte)
- 6F37 ACM maximum value (3 bytes)
- 6F38 SIM service table (2-4 bytes)
- 6F41 Price per unit and currency table (5 bytes)
- 6F45 Cell broadcast message identifier selection (variable length)
- 6F74 Broadcast control channels (16 bytes)
- 6F78 Access control class (2 bytes)
- 6F7B Forbidden PLMNs (see test 7) (12 bytes)
- 6F7E Location information (TMSI, Local Area Information (consist of MCC, MNC & LAC - see test 11 for them), last Location Update status) (11 bytes)
- 6FAD Administrative data (variable length)
- 6FAE Phase identification (1 byte)
- 6F43 SMS status (variable length)

Next two binary datafields are phase 2+ features which are not currently in use

- 6F3E Group Identifier Level 1 (variable length)
- 6F3F Group Identifier Level 2 (variable length)



## Display 53 – Writing datafield into SIM card

---

```
+++++++          #####
+   Write   +    # Use menu to#
+ data field +    # write data #
+from SIM-SCM+    #field to SIM#
+   to SIM   +    #           #
+++++++          #####
```

This display writes data for a binary datafield in SIM card by using data in SCM memory of SIM card.

Prior using this display the identifier of datafield has to be stored as an alpha-identifier of SCM location number 34 of SIM memory. The datafield must be written in hexadecimal notation. The identifiers can be found from the GSM 11.11. In addition the data to be stored into SIM card has to be entered as an alpha-identifier of SCM location number 35 of SIM memory. The data has to be stored in hexadecimal notation.

The result of write operation can be seen from the alpha-identifier of SCM-location 36 of SIM-memory and on the display for a short period.

The following results are possible:

```
OK datafield was read correctly
NOT BINARY datafield is either formatted or cyclic
NOT FOUND datafield was not found from SIM card
CARD ERROR something weird happened, card did not respond as expected
NO RIGHTS not enough rights to read the datafield (PIN2,adm..)
DATA ERROR the data contents in SCM location is coded wrongly
NOT STORED could not store into the result memory place
NO ADDRESS could not read the address from the SCM location
UNKNOWN unidentified error
```

If you want to see changes, often you have to restart your phone.

## Display 54 – Block display 1

---

```
+++++++          #####
+aa bb  aa bb+    #ResF1  ResF2#
+aa bb  aa bb+    #ResF3  ResF4#
+aa bb  aa bb+    #ResF5  ResF6#
+aa bb  aa bb+    #ResF7  ResF8#
+++++++          #####
```

1. row: Block set 1, block set 2
2. row: Block set 3, block set 4
3. row: Block set 5, block set 6
4. row: Block set 7, block set 8

aa        Number of reserved blocks  
bb        Number of free blocks in worst case

## Display 55 – Block display 2

---

```

+++++
+aa bb aa bb+
+aa bb aa bb+
+aa bb aa bb+
+aa bb aa bb+
+aa bb aa bb+
+++++
#####
#ResF9 ResF10#
#ResF11ResF12#
#ResF13ResF14#
#ResF15ResF16#
#####

```

1. row: Block set 9, block set 10
2. row: Block set 11, block set 12
3. row: Block set 13, block set 14
4. row: Block set 15, block set 16

aa            Number of reserved blocks  
bb            Number of free blocks in worst case

## Display 56 – Block display 3

---

```

+++++
+ aaaaaa bbb +
+ ccccccc +
+
+
+
+++++
#####
# Ptr Cntr #
# Task #
# #
# #
#####

```

aaaaaa        Pointer to memory where double deallocation was called, in hex format.  
bbb            Counter for failed deallocations.  
ccccccc        Name of task which last tried to double deallocate a block.

Note: This display is only valid when the counter for failed deallocations is not zero.

## Display 57 – Memory status before reset

---

```

+++++
+aaaaaaaaaaaa+
+aaaaa... +
+bbbbbbbb +
+
+
+++++
#####
# Status of #
# stacks #
# Block sets #
# #
#####

```

aaaaaa        Status of each stack before reset. First position contains the status of stack 0, second position the status of stack 1 and so on. The last position contains the status of System stack. Number of stacks depends on the current configuration of SW. Possible values for each stack are:  
0 : status OK, no overflow  
1 : status not OK, stack overflow,

bbbbbbb        Status of each block set before reset. First position contains the status of block set 1, second position the status of block set 2 and so on. Possible values for each block set are:  
0 : status OK  
1 : block set full  
2 : (de)allocation error or total memory corruption

## Display 60 – Reset counters to zero

---




```

*****
* FIELD TEST *
* DISPLAY *
* COUNTERS *
* RESET *
*****
#####
#Use menu to #
#reset field #
#test display#
# counters #
#####

```

With this display all counters of the field test display can be reset (i.e. all counters in 40 and 60 series).

## Display 61 (singleband) – Search and reselection counter display



```

+++++++
+NOPSW :aaaa+
+SYNCR :bbbb+
+RESELEC:cccc+
+      +
+++++++
#####
#PSWMsgCntr #
#SyncMeasCntr#
#CellReselCtr#
#      #
#####

```

- aaaa Counter for MDI\_NO\_PSW\_FOUND message received from DSP in hexadecimal form.
- bbbb Counter for synchronisation measurement attempts in decimal form. If counter value is over 9999 then four x are shown.
- cccc Counter for cell reselections in hexadecimal form.

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. These counters are automatically reset to zero when they exceed their maximum value.

## Display 61 (dualband) – Search and reselection counter display

```

+++++++
+aaaaa bbbbbb+
+cccccc dddddd+
+eeeeee ffffff+
+gggggg hhhhhh+
+++++++
#####
#NOPswGSM DCS#
#Sync GSM DCS#
#reselG>G D>D#
#reselG>D D>G#
#####

```

- aaaaa GSM counter for MDI\_NO\_PSW\_FOUND message received from DSP in decimal form (max 99999).
- bbbbbb DCS counter for MDI\_NO\_PSW\_FOUND message received from DSP in decimal form (max 99999).
- cccccc GSM counter for synchronisation measurement attempts in decimal form. If counter value is over 99999 then five x are shown.
- ddddd DCS counter for synchronisation measurement attempts in decimal form. If counter value is over 99999 then five x are shown.
- eeeeee Counter for GSM->GSM cell reselections in decimal form (max 99999).
- fffff Counter for DCS->DCS cell reselections in decimal form (max 99999).
- ggggg Counter for GSM->DCS cell reselections in decimal form (max 99999).
- hhhhh Counter for DCS->GSM cell reselections in decimal form (max 99999).

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. Counters are automatically reset to zero when they exceed their maximum value.

## Display 62 – Neighbour measurement counter display



```

+++++++
+ PSW :aaaa +
+ SYNCR:bbbb +
+ BCCH :cccc +
+ BCCH Ext:dddd +
+++++++
#####
#NeghbrPSWCtr#
#SyncMeasCntr#
#BCCHMeasAtmp#
#BCCHExtMeAtm#
#####

```

- aaaa Counter for neighbour PSW measurement attempts
- bbbb Counter for neighbour synchronisation measurement attempts
- cccc Counter for neighbour BCCH measurement attempts
- dddd Counter for neighbour BCCH Ext measurement attempts

Counter values are shown in hexadecimal form.

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. Counters are automatically reset to zero when they exceed their maximum value.

## Display 63 – Call attempts counters



```

+++++++
+ aa   bb +
+ ccc  ddd +
+ eee  fff +
+      +
+++++++
#####
#CalRel RelDi#
#MOCAtmp MOOK#
#AllMT  MTOK#
#      #
#####


```

- aa Reason of last call release
- 1: unassigned (unallocated) number
  - 3: no route to destination
  - 8: operator determined barring
  - 16: normal end of call
  - 17: user busy:  
if it was outgoing call, dialled number was busy (phone even displayed 'Number busy')
  - if it was incoming call, a man, who dialled to you, heard busy signal - you were speaking or you rejected it
  - 18: no user responding
  - 19: user alerting (phone displayed 'No answer') or when incoming call was diverted to voice mailbox, no answer
  - 21: call rejected: phone wasn't in network coverage (message 'No coverage network'), when you tried to make call, or you tried to call to non existing phone number or you heard busy signal
  - 22: number changed
  - 27: destination out of order
  - 28: invalid number format/number incomplete. Phone displayed 'Invalid phone number'
  - 31: unspecified. It seems, that with this error connection is end by network (for example, when it's overcharged). Shown sometimes too, when you call for not supported for some tariffs numbers.
  - 34: no circuit/channel available to make call. Phone displayed 'Network busy'.
  - 38: network out of order
  - 41: temporary failure
  - 42: switching equipment congestion (message "Network busy")
  - 44: requested channel not available
  - 47: resource unavailable. Phone displayed 'Error in connection' for example because of empty battery
  - 50: requested facility not subscribed. Message "Check operator services".
  - 65: bearer service not implemented
  - 68: ACM equal to or greater than ACMmax
  - 69: requested facility not implemented
  - 79: error with message 'Check operator services'. You have it, when you enable ALS (Alternative Line Service) function, don't have second number on SIM card, select it and try to make call
  - 88: incompatible destination
  - 111:'Error in connection'
- bb Direction of last call release
- UN : Unknown
  - MO : Mobile originated
  - MT : Mobile terminated
  - IN : Internal (ME CS sw)
- ccc Count of all MO call attempts made
- ddd Count of succeeded MO calls
- eee Count of all call setups received
- fff Count of succeeded MT calls

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. Counters are automatically reset to zero when they exceed their maximum value.

## Display 64 – Location Update attempts counters

---



```

+++++++
+ aa bbb ccc +
+ dd eee fff +
+           +
+           +
+++++++
#####
#Nfai NL NLOK#
#PFai PL PLOK#
# Loc update #
# counters #
#####


```

- aa Reason of last normal location update failure
- bbb Count of normal location update attempts
- ccc Count of succeeded normal location updates
- dd Reason of last periodic or IMSI attach location update failure
- eee Count of all periodic and IMSI attach location update attempts
- fff Count of succeeded periodic and IMSI attach location updates

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. Counters are automatically reset to zero when they exceed their maximum value.

## Display 65 - SMS attempts counters

---



```

+++++++
+ aa bbb ccc +
+ dd eee fff +
+ gggg      +
+           +
+++++++
#####
#SFai MO MOOK#
#RFai MT MTOK#
#Sched Msgs #
#SMS counters#
#####


```

- aa Reason of last sending failure
  - 1: 'Number not in use'
  - 21: 'Message not sent this time'. This error happens, when you try to send messages from prepaid card without this possibility, when you send message for incorrect number (SMSC is correct), SMSC is blocked on your network or when you send SMS with alphanumeric number over SMSC, which doesn't support it.
  - 28: 'Number not in use'
  - 38: 'Message not sent this time'. Error with sending message during SMSC blocked on your network.
  - 42: probably phone shows this error, when used SMSC is overworked (too many sent messages in the same time) and can't send your message in this moment
  - 50: 'Check operator services'. Error displayed after sending SMS from some prepaid cards without this possibility.
  - 96: 'Message sending failed'. The reason is wrong number of SMSC
  - 111: 'Message sending failed'. The reason is wrong target number or wrong number of SMSC
  - 166: 'Message sending failed'. Displayed when SMSC number was wrong or SMSC is blocked for your network
  - 178: 'Message sending failed'. Error displayed after sending SMS from some prepaid cards without this possibility
  - 252: 'Message sending failed'. Displayed, when phone's transmitter was disabled in test 45 or phone can't find network (when BTS test in test 17 was enabled on channel without network)
  - 253: 'Message sending failed'. Displayed, when SMSC number was wrong
- bbb Count of all MO short message attempts
- ccc Count of succeeded MO short message attempts
- dd Reason of last receiving failure
  - 22: full memory for SMS messages
- eee Count of all MT short message attempts
- fff Count of succeeded MT short message attempts
- gggg Count of all received cell broadcast schedule messages

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. Counters are automatically reset to zero when they exceed their maximum value.

## Display 66 - SMS timeout counters

---



```

+++++++
+ aaa bbb cc +
+ ddd eee ff +
+
+
+++++++
#####
#TR1 TR2 TRA #
#TC1 TC2 SCH #
#SMS timeout #
# counters #
#####

```

- aaa Counter for TR1M timeouts
- bbb Counter for TR2M timeouts
- cc Counter for TRAM timeouts
- ddd Counter for TC1M timeouts
- eee Counter for TC2M timeouts
- ff Counter for CB schedule timeouts

On power off the values of the counter displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, select display 60. Counters are automatically reset to zero when they exceed their maximum value.

## Display 70 - Temporary counters of DSP

---

```

+++++++
+ aaaa bbbb +
+ cccc dddd +
+ eeee ffff +
+ gggg hhhh +
+++++++
#####
# Temporary #
#DSP counters#
#(R DSP2FTD) #
#
#
#####

```

- aaaa Contents of API memory location r\_dsp2ftd+0 in hex format
- bbbb Contents of API memory location r\_dsp2ftd+1 in hex format
- cccc Contents of API memory location r\_dsp2ftd+2 in hex format
- dddd Contents of API memory location r\_dsp2ftd+3 in hex format
- eeee Contents of API memory location r\_dsp2ftd+4 in hex format
- ffff Contents of API memory location r\_dsp2ftd+5 in hex format
- gggg Contents of API memory location r\_dsp2ftd+6 in hex format
- hhhh Contents of API memory location r\_dsp2ftd+7 in hex format

The display is to be used by special debugging DSP SW which can put some useful information to the memory locations on API RAM. When this display is selected then MCU copies the contents of those memory locations into display with format specified above.

## ***Display 71 - Control DSP audio enhancements 1***

---

```
*****          #####  
*AUDIO          *      #Use menu to #  
*ENHANCEMENT   *      #control DSP #  
*DISPLAY 1     *      #  audio  #  
*   XXXXX     *      #enhancements#  
*****          #####
```

XXXXX Control word for DSP Audio Enhancements in decimal format.  
The control word is sent to the DSP in mdi audio configure message.

Prior using this display the control word must be written to location 31 of SIM-card in decimal format.

When the display 71 is chosen from the menu, (EXECUTE MODE) the control word is sent to the DSP in mdi audio configure message immediately. Mdi audio configure message is also sent every time when this display is entered using arrow keys and previous display was 72.

Used together with display 72, this display makes rapid on/off switching of audio DSP algorithms possible. Switching with arrow keys is possible only after this display or display 72 has been selected from the menu. This prevents accidental on/off switching of algorithms when browsing displays by arrow keys. Entered values are not saved to EEPROM.

## ***Display 72 - Control DSP audio enhancements 2***

---

```
*****          #####  
*AUDIO          *      #Use menu to #  
*ENHANCEMENT   *      #control DSP #  
*DISPLAY 2     *      #  audio  #  
*   XXXXX     *      #enhancements#  
*****          #####
```

XXXXX Control word for DSP Audio Enhancements in decimal format.  
The control word is sent to the DSP in mdi audio configure message.

Prior using this display the control word is written to SCM-location 32 of SIM-card in decimal format.

When the display 72 is chosen from the menu, (EXECUTE MODE) the control word is sent to the DSP in mdi audio configure message immediately. Mdi audio configure message is also sent every time when this display is entered using arrow keys and previous display was 72.

Used together with display 71, this display makes rapid on/off switching of audio DSP algorithms possible. Switching with arrow keys is possible only after this display or display 71 has been selected from the menu. This prevents accidental on/off switching of algorithms when browsing displays by arrow keys. Entered values are not saved to EEPROM.

## Display 73 - Generic display for DSP Audio Enhancements

---

```
+++++++      Example display:      ++++++
+ aaa bb  aaa+                      + 101 00  408+
+cccc bb  cccc+                      +BCDE 88 7FFF+
+cccc bb  cccc+                      +0001 FF 0003+
+ cccc cccc +                        +  DEAD DEFA +
+++++++      ++++++
```

aaa General dB value, e.g. signal level in dB. decimal point and sign is not shown, ie. -10.5 is show 105.  
bb General byte value, used for combined flags. Value is in hex format.  
cccc General hex value.

The display is reset and restarted when call is taken (if FT display counters are enabled). When call is terminated the display is frozen to show last values. Display values will not be saved to the EEPROM.

HELP display:

```
#####
#DB1  B1  DB2#
#HEX1 B2 HEX2#
#HEX3 B3 HEX4#
#  HEX5 HEX6 #
#####
```

## Display 74 - DSP audio enhancements 1 (DRC)

---

```
+++++++      Example display:      ++++++
+  aaa  bbb  +                      +  101  408  +
+          ccc +                      +          480 +
+  dd    ee  +                      +  01    03  +
+          +                          +          +
+++++++      ++++++
```

aaa Downlink signal level in dB, calculated using DRC level measuring block. Decimal point and sign is not shown, ie. -10.5 is show 105.  
bbb Uplink signal level in dB, calculated using DRC level measuring block. Decimal point and sign is not shown, ie. -10.5 is show 105.  
ccc Background noise signal level in dB, calculated using DRC level measuring block, decimal point and sign is not shown, ie. -10.5 is show 105.  
dd Downlink DRC table value, shown in decimal integer, two digits.  
ee Uplink DRC table value, decimal integer, two digits.

The display is reset and restarted when call is taken (if FT display counters are enabled). When call is terminated the display is frozen to show last values. Display values will not be saved to the EEPROM.

HELP display:

```
#####
#DSigL USigL #
#      NseLvl#
# DTbl  UTbl  #
#          #
#####
```



## Display 75 - Audio path status

---

```

+++++#####
+Mod:aaaaaaa+  #ExtAudStatus#
+AudReq: bbbb+  #AudioRequest#
+AccMod: cccc+  #AccessoryMod#
+H2Path: dd  +  #HFU2Path  #
+++++#####

```

aaaa External audio status, values are: HP, HF, HEADSET, EXT and HP\_OFFHO  
bbb Audio\_request bitmap in hex, contents (masks) are specified in AUD\_DATA.H  
ccc Accessory audio mode  
dd HFU-2 path

## Display 76 - Ear (= downlink) audio display

---

```

+++++##### Example display: +++++#####
+ Vaa Pbbb +      + V0A P125 +
+ Cccc CAddd +    + C000 CA001 +
+PAeee +          +PA353 +
+ + +            + + +
+++++#####      +++++#####

```

aa Volume level.  
bbb Peak value of downlink audio signal during last frame in dB, decimal point and sign is not shown, ie. -10.5 is show 105.  
ccc Cut off counter value of last frame. This counter counts how many samples are saturated during last frame.  
ddd Moving average of cut off counter, decimal point and sign is not shown, ie. -10.5 is show 105.  
eee Moving average of peak levels.

The display is reset and restarted when call is taken (if FT display counters are enabled). When call is terminated the display is frozen to show last values. Display values will not be saved to the EEPROM.

HELP display:

```

#####
#EVol PeakVal#
#CutOff COAve#
#PkAver #
# #
#####

```

## Display 77 - Microphone (= uplink) audio display

---

```

+++++++      Example display:      ++++++
+ Paaa  Abbb +                      + P303  A225 +
+ Cccc  CAddd +                      + C023  CA003 +
+                +                      +                +
+                +                      +                +
+++++++      ++++++

```

- aaa Peak value of uplink audio signal during last frame in dB decimal point and sign is not shown, ie. -10.5 is show 105.
- bbb Moving average of peak levels, decimal point and sign is not shown, ie. -10.5 is show 105.
- ccc Cut off counter value of last frame. This counter counts how many samples are saturated during last frame.
- ddd Moving average of cut off counter

The display is reset and restarted when call is taken (if FT display counters are enabled). When call is terminated the display is frozen to show last values. Display values will not be saved to the EEPROM.

HELP display:

```

#####
#MicPeak MAve#
#CutOff COAve#
#           #
#           #
#####

```

## Display 78 - DSP audio enhancements (AEC)

---

```

+++++++      #####
+aaa bbb ccc +      #EAA Ada ERL #
+ddd eee fff +      #RxG TxG GLi #
+ggg h i jjj +      #TxN Sta Mod #
+kkkk llll +       # RVAD TVAD #
+++++++      #####

```

- aaa Electro-acoustic attenuation of echo from DSP point of view in dB. Decimal point and sign is not shown. E.g. -10.5dB would be displayed as "105", -0.5 dB would be displayed as " 5".  $20 \cdot \log_{10}(Q15)$
- bbb Adaptive attenuation of echo. Decimal point is not shown.  $20 \cdot \log_{10}(Q15)$
- ccc Total echo return loss. Decimal point is not shown.  $20 \cdot \log_{10}(Q15)$
- ddd RX attenuator gain in dB. Decimal point and sign is not shown.  $20 \cdot \log_{10}(Q15 \text{ aec\_rx\_gain})$
- eee TX attenuator gain in dB. Decimal point and sign is not shown.  $20 \cdot \log_{10}(Q15 \text{ aec\_tx\_gain})$
- fff Gain limit for RX and TX. Decimal point and sign is not shown.  $20 \cdot \log_{10}(Q15 \text{ aec\_gain\_limit})$
- ggg TX noise level in dB. Decimal point and sign is not shown.  $20 \cdot \log_{10}(Q15 \text{ aec\_tx\_noise})$
- h Adaptive filter status. (Q0 aec\_nlms\_state) (bit UPDATE << 2) | (bit NLMS2 << 1) | (bit NLMS1)
- l Comfort noise generation (0 or 1) (Q0 AEC\_TX\_COMF\_GEN)
- jjj AEC mode. (byte Q0 s\_AEC\_mode)
- kkkk Shows 16 last RX VAD decisions in HEX format. Hex(Q0 aec\_rx\_vadreg)
- llll Shows 16 last TX VAD decisions in HEX format. Hex(Q0 aec\_tx\_vadreg)

## Display 79 - Audio equalizer display

---

```

+++++      Example:  +++++      #####
+aaaaa bbbbb +      +12345 54321 +      #MiCutB MiCTA#
+ccccc ddddd +      + 2353 46187 +      #EpCutB EPCTA#
+-ee.e -ff.f +      +-46.5 -27.4 +      #MicLev EarLv#
+          +          +          +          #          #
+++++      +++++      #####

```

aaaaa Saturated samples before microphone equalizer in decimal 16 bit unsigned integer format.  
 bbbbb Saturated samples after microphone equalizer in decimal 16 bit unsigned integer format.  
 ccccc Saturated samples before earpiece equalizer in decimal 16 bit unsigned integer format.  
 ddddd Saturated samples after earpiece equalizer in decimal 16 bit unsigned integer format.  
 -ee.e Level of the microphone signal level detector in dB format.  
 Requires log10 function in MCU. 16 bit signed value in DSP, 0 dB = 32768.  
 -ff.f Level of the signal after earpiece equalizer in dB format.  
 Requires log10 function in MCU. 16 bit signed value in DSP, 0 dB = 32768.

The display is reset and restarted when call is taken. When call is terminated the display is frozen to show last values. Display will not be saved to EEPROM. Saturated sample counters aaaaa - ddddd are counted in DSP and only the new counter value is sent to MCU. The microphone and earpiece signal levels are calculated in DSP and it sends the linear values to MCU which makes the linear to dB transformation ( $20 \cdot \log_{10}(x)$ ) for the level values.

## Display 80 - Reset and restart timers

---



```

*****      #####
*          *      # Use menu #
*   TIMERS   *      # to reset  #
*   RESET    *      # field test #
*          *      #   timers  #
*****      #####

```

With this display all timers of the display 82 can be reset. These timers will be automatically reset after the battery has been fully charged and the charger is disconnected. Thus it's not always necessary to use the display 80.

## Display 81 - Enable or disable timers

---



```

*****
*          *
*   TIMERS   *
*   XXXXXXXX *   XXXXXXXX   ENABLED or DISABLED
*          *
*****

```

This display will start or stop the timers. On power off the values of the timer displays are stored onto the EEPROM, where they will be read during power on. To initialise the counters to zero, use display 80. Timers will be automatically disabled when recharge battery message is reached. Also the current state of timer disabling/enabling is stored onto the EEPROM.

HELP display:

```

#####
#Use menu to #
#control test#
# display  #
# timers   #
#####

```

## Display 82 - Test timer display

---



```

+++++++
+aaaaa bbbbb +
+ccccc ddddd +
+ TIMERS eee +
+           +
+++++++
#####
#PwrOn InServ#
#NSPS TxON #
# Timers #
# Status #
#####

```

aaaaa Timer for how long the phone has been powered on  
 bbbbb Timer for how long the phone has been in service  
 ccccc Timer for NO-SERV POWER-SAVE state  
 ddddd Timer for how long the transmitter has been on  
 eee State of timers, ON/OFF

All the values are shown in one minute resolution. The accuracy of the timers is about one second. The display uses following format for timers:

HHHMM where HHH is hours and MM is minutes.

All timers of this display will be reset if the charger is disconnected from the mobile with fully charged battery. The maximum value of the timers is 99 h 59 min. When 'powered on' timer has reached value 9959, all timers will be stopped.

NOTE: When the maximum usage time of the phone is required (e.g. idle time measurement) then ALL field test displays must be deactivated!

## Display 83 - Control of task information displays

---

```

*****
*           *
* SHOW TASK *
* XXXXXXXXX *   XXXXXXXXX is "STACKS", "MSG BUFS" or "FAST BUFS"
*           *
*****

```

Shows what information about tasks is currently shown in displays 84 - 87.

To select the type of information select this display via menu.

Type is changed in order STACKS -> MSG BUFS -> FAST BUFS -> STACKS.

So, if STACKS is currently displayed and you want to see FAST BUFS, you have to select this display twice via menu.

"STACKS" shows free stack space in worst case.  
 "MSG BUFS" shows the peak number of pending messages.  
 "FAST BUFS" shows the peak number of pending fast messages.

HELP display:

```

#####
#Use menu to #
#select shown#
# task info #
#           #
#####

```

## ***Display 84 - Information of task numbers 0 - 7***

---

```
+++++
+ aaaa bbbb +
+ cccc dddd +
+ eeee ffff +
+ gggg hhhh +
+++++
```

```
aaaa    task 0
bbbb    task 1
cccc    task 2
dddd    task 3
eeee    task 4
ffff    task 5
gggg    task 6
hhhh    task 7
```

Numbers tell how many stack memory locations have been empty in the worst case. So, if number is zero, stack has been full.

Values are not stored to EEPROM.  
Task names are listed on help display.

## ***Display 85 - Information of task numbers 8 - 15***

---

```
+++++
+ aaaa bbbb +
+ cccc dddd +
+ eeee ffff +
+ gggg hhhh +
+++++
```

```
aaaa    task 8
bbbb    task 9
cccc    task 10
dddd    task 11
eeee    task 12
ffff    task 13
gggg    task 14
hhhh    task 15
```

Values are not stored to EEPROM.  
Task names are listed on help display.

## ***Display 86 - Information of task numbers 16 - 23***

---

```
+++++++
+ aaaa bbbb +
+ cccc dddd +
+ eeee ffff +
+           +
+++++++

aaaa    task 16
bbbb    task 17
cccc    task 18
dddd    task 19
eeee    task 20
ffff    task 21
gggg    task 22
hhhh    task 23
```

Values are not stored to EEPROM.  
Task names are listed on help display.

## ***Display 87 - Information of OS\_SYSTEM\_STACK***

---

```
+++++++ #####
+ aaaa bbbb + # FIQ IRQ #
+           + #           #
+           + #           #
+           + #           #
+++++++ #####

aaaa    OS_SYSTEM_STACK
```

Values are not stored to EEPROM.

## ***Display 88 - Information of the current MCU and DSP software versions***

---

```
+++++++ #####
+aaaaa bbbbbb+ #MCUSW PPM #
+Date ccccc+ #MCUSW_Date #
+ChkSum dddd + #MCU_Checksum#
+eeeeeeeeeee+ #DSP_Version #
+++++++ #####

aaaaa    Version number of MCU SW (e.g. 5.02)
bbbbbbb  PPM version (e.g. 5.02A)
cccccc   Date of version (e.g. 990102 means 02. January 1999)
dddd     MCU SW checksum
eeeeeeee  Version of DSP software
```

## Display 89 - Information of the current HW and TXT versions

---

```
+++++++
+HW: aaaa +      #####
+TXT:bbbbbbb +   #HW Version #
+          +     #Text Version#
+          +     #           #
+          +     #           #
+++++++
#####
```

aaaa                   Hardware version (e.g. 2350)  
bbbbbb                 Text version (e.g. U190199)

## Display 90 - Misc counters

---

In Nokia 9110 this test looks like follows:

```
+++++++
+Cover aaaa +    #####
+CarKit bbbb +   # CoverCnt  #
+Heads cccc +   # CarKitCnt  #
+          +   # HeadsetCnt #
+          +   #           #
+++++++
#####
```

aaaa           - how many times Communicator's cover was opened  
bbbb           - how many times carkit was connected  
cccc           - how many times headset was used

In Nokia 7110/8210/6210 looks like follows:

```
+++++++
+PS0 aaaa +     #####
+EC0 bbbbbbbb+ #Page0 Status#
+PS1 cccc +     #EraseCounter#
+EC1 dddddddd+ #Page1 Status#
+          +     #EraseCounter#
+++++++
#####
```

aaaa           - the same to the parameter bbbb from test 92  
bbbbbbb       - the same to the parameter ddddddd from test 92  
cccc           - the same to the parameter bbbb from test 93  
ddddddd       - the same to the parameter ddddddd from test 93

## ***Display 91 - Misc counters / Reseting counters***

---

In Nokia 9110 this test looks like follows:

```
*****          #####
*   RESET      *   # Use menu #
*   MISC       *   # to reset #
*   COUNTERS   *   #  misc   #
*              *   # counters #
*****          #####
```

By direct enter to this test you can reset counters from test 90.

In Nokia 7110/8210/6210 this test is different:

```
+++++++          #####
+FL 005FC998+    #NextEntry #
+E2  0  0+      #Addr Length#
+PR  30  1+     #Small Long#
+OM  0 0000+    #ErCnt ErMask#
+++++++          #####
```

## ***Display 92, 93 - Misc counters / Toggle headset***

---

In Nokia 9110 test 92 looks like follows:

```
*****          #####
*              *   #Use menu to #
*   Headset    *   # toggle   #
*   xxx        *   # headset  #
*              *   # ON/OFF   #
*****          #####
```

xxx = ON or OFF

By direct enter to this test you can enable "headset" profile normally accessible after connecting headset. When you will use it, value of counter from test 90 don't change.

Use this test, when you need 'Automatic Answer' function, which allow to receive incoming call without pressing phone's key. This function is normally enable in never Nokia phones with connected set only (in older phones - like Nokia 2110i - it's always visible).

In Nokia 7110/8210/6210 test 92 and 93 are different:

```
+++++++          #####
+EP aaaa bbbb+  #EMark PgStat#
+#0   cccc+     #PgType   #
+   dddddddd+  #EraseCount #
+eeeeeeeeeeee+ #PpInd PpECnt#
+++++++          #####
```

bbbb - the same to the parameter aaaa from test 90  
ddddddd - the same to the parameter bbbbbbb from test 90



## Display 95 - Lowest values at shut down

---

```
+++++++
+1:aaa 4:ddd +      #####
                    # 6 lowest  #
+2:bbb 5:eee +      # values at #
+3:ccc 6:fff +      # shut down #
+           +      #           #
+++++++
                    #####
```

## Display 96 - Temperature

---

In Nokia 3210 this test looks like follows:

```
+++++++
+VCX0ADC: aaa+      # ADC VALUE #
+TEMP(C): bb+       # RF TEMP(C) #
+TEMP(K): ccc+      # RF TEMP(K) #
+           +      #           #
+++++++
                    #####
```

- bb - temperature of bb counter (in Celsius degrees)
- ccc - temperature of bb counter (in Kelvin degrees:  $K = C + 273$ )

In Nokia 7110 this test looks different, for example:

```
+++++++
+Co:49 A: 279+      #Contrast ADC#
+Tu:49 K: 305+      #Tuned Kelvin#
+Of: 0 C:+32 +      #Offset C #
+v5: 2           +      #           #
+++++++
                    #####
```

## Display 99 - Enabling FBUS protocol

---

In Nokia 8810 this test looks like follows:

```
*****
* ENTERING *      # Switches #
* FBUS *        # phone #
* MODE *        # to FBUS #
*           *      # mode #
*****
                    #####
```

For enabling FBUS protocol instead of normal used infrared connection.

In Nokia 7110 this test looks different (similar is in Nokia 6210):

```
+++++++
+ Ead:aaaa +      # EAD value #
+ Mod:bb +       # Acc. status#
+ MODE: cccc +    # FBUS mode #
+ V5: 2 +        #           #
+++++++
                    #####
```

- bb - type of connected sound accessories (example values: HP in normal state, HD with headset - for example HDC-9P, DC for datacable). In other phones this information is displayed in test 75
- cccc - "FBUS" in connection made during FBUS or MBUS cable from older Nokia phone (5xxx, 6xxx) or during Irda connection

## Display 100 - Information about using phone's memory / voice dialling feature

In Nokia 9110 this test looks like follows:

```
+++++
+ a b + #####
+ c ddd e + # UWS DWS #
+ # T1 N1 T2 #
+ # #
+ # #
+++++
```

In Nokia 7110/6210 this test looks like follows:

```
+++++
+ XXXX aa.a* + #####
+ YYYY bb.b* + #MemUseT %Use#
+ ZZZZ cc.c* + #MemRelT %Rel#
+ # #
+++++
```

aa.a the usage (% used) of the internal memory (phonebook, tasks, calendar, logos, ring tones etc.)  
bb.b the usage (% used) of the phonebook memory  
cc.c the amount (% not used) of free memory available

And in Nokia 8210/3310 is different (they're information about the voice dialling feature):

```
+++++
+ ND a b c+ #####
+ d e f+ #ND mm cs ps #
+ # ss po da #
+ # #
+ggggg hhhhhh+ #Vers: Date: #
+++++
```

a - number of recorded voice tags in phone. Maximal value is 8 (for Nokia 8210/3310) or 10 (for Nokia 6210). It's displayed in test 101 and test 102 (Nokia 8210/3310) or test 108 and test 109 (Nokia 6210)  
c - info about using voice dialling engine:  
0 - it wasn't used after enabling phone  
1 - voice tag was not recognised or Play/Save function were used  
5 - voice tag was recognised  
7 - user was in voice dialling function menu and selected Cancel function  
ggggg - version of voice dialling engine (?)  
hhhhh - date of releasing voice dialling engine (?)

Values of counters (without "a" parameter) are not saved to EEPROM, when phone is disabled.

## ***Display 101 - Information about TX & RX frames / voice dialling feature***

---

In Nokia 9110 this test looks like follows:

```
+++++#####
+ aaaaaaaa + #TX Frame Cnt#
+ bbbbbbbb + #RX Frame Cnt#
+ cccccccc + #TX Retx Cnt #
+ dddddddd + #RX Tetx Cnt #
+++++#####
```

All values are in hexadecimal values.

In Nokia 7110/6210 this test looks like follows:

```
+++++#####
+ #0 0 #1 0 + #Pn LoCPn LoC#
+ #2 0 #3 0 + #Pn LoCPn LoC#
+ #4 0 #5 0 + #Pn LoCPn LoC#
+          + #          #
+++++#####
```

Information about using phone's memory (information displayed here is probably about phonebook memory).

And in Nokia 8210/3310 it's different again (information about the recording voice tags in voice dialling feature):

```
+++++#####
+ Train      + # Train      #
+ a  b  c  + # r  ii  mm  #
+ dddd  eeee + # strt  durn #
+ ffff  gggg + # minm  maxm #
+++++#####
```

- a - number of voice tags failed to record (it increases for example, when phone didn't recognise any voice to record)
- b - number of recorded tags, when this test was enabled
- c - number of recorded tags in phone. Maximal value is 8 (for Nokia 8210/3310) or 10 (for Nokia 6210). It's displayed in test 100 and test 102 (Nokia 8210/3310) or test 107 and test 109 (Nokia 6210).
- dddd - how loud was start of recorded voice during last recording (the higher, the more loud)
- eeee - how loud was recorded voice during last recording (the higher, the more loud)
- ffff, gggg - another parameters unique to each recorded voice (hex values ?)

Values of counters (without "c" parameter) are not saved to EEPROM, when phone is disabled.

## ***Display 102 - Information about data call flow control / voice dialling feature***

---

In Nokia 9110 this test looks like follows:

```
+++++#####
+aaaaaaaaa + # Data call #
+bbbbbbbbbb+ #flow control#
+ccccccccc + # info #
+ + # #
+++++#####
```

In Nokia 8210/3310 it's different (information about the recognising voice tags in voice dialling feature):

```
+++++#####
+ Recog a b+ #Recog r mm #
+ c dddd eeee+ #i1 scr1 minm#
+ f gggg hhhh+ #i2 penH maxm#
+ i jjjj kkkk+ #i3 penL penC#
+++++#####
```

b - number of recorded tags in phone. Maximal value is 8 (for Nokia 8210/3310) or 10 (for Nokia 6210). It's displayed in test 100 and test 101 (Nokia 8210/3310) or test 107 and test 108 (Nokia 6210)

2nd line - info about last recognised by phone voice tag (c = number of voice tag)

3rd line - info about previous recognised by phone voice tag (f = number of voice tag)

4th line - info about previous recognised by phone voice tag (i = number of voice tag)

Values of counters (without "b" parameter) are not saved to EEPROM, when phone is disabled.

## ***Displays 110-115 - WAP settings?***

---

```
+++++#####
+0 FFFE 0.0 + # Pn Sta %Use#
+000002 0.0+ # EraseCn %Rel#
+000000 100.0+ # NextRec %Unu#
+ 3 1 0 FFE0+ # Cu Cl Cc MmC#
+++++#####
```

Probably connected with browser and another settings of connections to WAP.

## ***Display 130 - Sliding cover counter / DSP resets***

---

In Nokia 7110 this test looks like follows:

```
+++++#####
+ aaa bbbbbb + # Slide Open #
+           + #           #
+           + #           #
+           + #           #
+++++#####
```

bbbbbb - how many times phone's sliding cover has been opened. Value is shown in hexadecimal.

In Nokia 3310 it's different:

```
+++++#####
+DSP_RST:aaaa+ #DSP resetcn #
+CS: bbbbbb+ #CStandbyLoss#
+ cc dd ee ff+ #sw as pw st #
+0000 gggg + #BadPwr insim#
+++++#####
```

aaaa - number of DSP resets. Displayed also in test 36

## ***Display 131 - Sum of handovers***

---

```
+++++#####
+STO:aaaaaaaa+ #Stack overfl#
+NB:bbLB:cc + #NoBuf LongBu#
+HOF:ddddddd+ #HandOver Cnt#
+eeee ZR:ffff+ #HOfail ZonFa#
+++++#####
```

ddddddd - sum of handovers from test 41 (?). Unfortunately, values don't match always (firmware bug ?)

Counters are in hexadecimal form.

## ***Display 132 - Received calls counter***

---

```
+++++#####
+BS: aaaaaaaa+ #BS_Call Cnt #
+MO: bbbbbb+ #MO_Call cnt #
+DRC:cccccccc+ #Dropped call#
+TIM:ddddddd+ # Call time #
+++++#####
```

aaaaaaaa - how many times you received call. Please notice one difference to MTOK parameter from test 63: you can't reset this value from phone's menu

bbbbbbb - how many times you made successful outgoing call from your phone. Please notice one difference to MOOK parameter from test 63 - you can't reset this value from phone's menu. One interesting thing: this counter can have bigger value than MOOK from test 63 (firmware bug ?)

Counters are in hexadecimal form.

## ***Display 133 - Displayed info about full charged battery counter***

---

```
+++++#####  
+BFu:aaaaaaa+ #FullChargCnt#  
+ChC:bbbb cc+ #ChaCon Wrong#  
+StB: + #Standby time#  
+NSe: + #NoServTimer #  
+++++#####
```

aaaaaaa - how many times info about full charged battery was displayed (when it was done correctly - for example FullM info in test 20...or not - for example MaBFD info in the same test). Counter doesn't increase value, when phone is disabled.

bbbb - how many times charger was connected. Counter increases value, when (each time, when you will do it):

- phone is enabled, you connect charger
  - phone is disabled, you connect charger and enable phone
- Counter doesn't increase, when phone is disabled.

## ***Display 240 - Zero and start counters***

---

Following actions performed:

- reset handover counters (display 40)
- reset counters to zero (display 60)
- reset timers (display 80)
- enable timers (display 81)

The active field test display is not affected.

## ***Display 241 - Disable field test display***

---

The field test display is totally disabled by writing the EEPROM value.

## ***Display 242 - Disable RD field test displays***

---

The R&D field test displays are disabled by writing the EEPROM value.

So only the displays 1-19 are active after this command.

The active field test display is not affected.

## ***Display 243 - Enable RD field test displays***

---

Enables full NetMonitor.

## ***Display 245 - Clear OS post-mortem dump information***

---

To clear OS post-mortem dump information displays, i.e. only display 57 in DCT3.

The active field test display is not affected.